

Adjusting The Hunter MP Rotator Sprinkler

This guide focuses on how to adjust the Hunter MP Rotator, this sprinkler is ideal for Garden Irrigation to help water grass or lawns.



Below is an example image of this item, it can be adjusted so that it points in different directions or so that it has a higher or lower spray arc. You can use multiple sprinklers to help water big lawns or for patches where you need to cover a large distance.



Arc Adjustment

1. Install the MP Rotator with the Left Edge Indicator pointing to the left side of the desired watering pattern.
2. With the MP Rotator operating and in the pop-up position, rotate the Arc Adjustment Ring. Turning the Arc Adjustment Ring clockwise will increase the arc, counter clockwise will decrease the arc.

Radius Adjustment

Factory setting is for full radius, and the radius can be reduced by 25%. With the MP Rotator tool or a small flat bladed screwdriver, rotate the Radius Adjustment Screw:

- Clockwise (4 full turns) to decrease the radius
- Counter-clockwise (4 full turns) to increase the radius

Copyright 2016 Garden Magic Ltd. Information is advisory only, and we cannot accept any responsibility for incorrect use or application of information given. We always recommend the use of a qualified electrician for 240 volt lights, and always recommend following the manufacturer's instructions on 12 volt systems, solar lights or any Garden Irrigation equipment.

If you require any extra help, a garden design service or even a link to our other articles then feel free to send any enquiries to sales@gardenmagicworld.com